



INSTALLATION INSTRUCTIONS FOR THE GONDOLA A-FRAME ASSEMBLY

CZ4-6730 DOUBLE SIDED A FRAME ASSEMBLY INSTRUCTIONS

1. Set a **CZ2-6730** Ender upright, then hook a **CZ4-8604B**, Bottom Connector Bar into the bottom two slots. Be sure the channel portion is facing up. Repeat for the other ender. Hook a **CZ4-4806T**, Top Connector Bar into the **4th** and **5th** slots from the top, making sure the channel portion faces down. Insert into the other ender.
2. Slide one of the **Anti-Sway Bars** into the **6th** slot from the top and then into the **3rd** slot from the bottom. Repeat for the other Anti-Sway Bar, installing in an X pattern.
3. Loosely install the ¼-20 bolt and nut in the Anti-Sway Bar. Do not tighten yet.
4. Drop the base deck **CZ4-4812** onto the feet by inserting the side tabs into the slots on the top of the foot bars.
5. Insert one of the sign holder bars **CZ4-0747** into the 3rd slot from the top of the post with the gap facing up.
6. Place two clear sign holder plexi pieces BR4-4805 into the bottom bar and then add another sign holder bar with the gap facing down into the first slot so that the plexi is held in place between the two. Now you can secure the assembly by tightening the Anti-Sway Bolt assembly.
7. Insert the post cap CZ4-0202 into the top of the posts. If you are adding additional sections to the starter it is recommended that you construct all of the frame assemblies and level them in the desired place before adding the shelf assemblies.